

Directions for use:

Spa Purge

1. Remove cartridge filter elements
2. With spa water temperature at 95 degrees or higher, add entire contents of 1L Spa Purge bottle to spa water
3. Run jets a minimum of 5 minutes. (Note: if excessive foaming occurs, turn jets off)
4. Maintain water temperature and allow spa to circulate overnight with jets off
5. Drain, rinse and then re-fill spa and re-install filter elements. Proceed with normal spa maintenance

Note: For jetted tubs, use 1/2 bottle of **Spa Purge**