


RC35 HWI AQUAVAC 250 Li Spare Part List

4-May-20



	Description	HAYWARD P/N
1	Swivel head (with flap + ring + scew plate)	RCX20ASM05U (US) RCX20ASM05E (EU)
2	Side flap (with side pin)	RCX203007
3	Swivel smooth-ring	RCX203508004
5	Swivel head bottom screw plate	RCX203505005
4	Top cover	RCX20ASM03
6	Filter cover	RCX203509
7	Whole base unit	RCX2035ASM06
8	Wheel (with screw and washer) 1pc	RCX203012
9	Clip-on rake	RCX2032ASM10
10	Clip-on brush	
11	Drainage outlet flap (with screws)	RCX2035ASM04
12	Suction mouth flap (with screws)	
13	Bumper x 2	RCX203018
14	Float	RCX203513
15	Hook (with V-clip) for Telescopic pole)	RCX203116
16	Charging base	RCX203017
17	Adaptor	RCX203017U (US) RCX203017E (EU)