Directions for use:

Filter Perfect

Cartridge Elements or DE filter grids

- Remove cartridge elements or DE grids from filter tank and hose off loose material
- 2. In a pail, bucket or trash container with 5-10 gallons of water, add 1L bottle of Filter Perfect
- 3. Place cartridge elements or DE grids in solution and soak for a minimum of 6 hours (preferably overnight)
- 4. Remove from solution and rinse thoroughly

Note: Clean cartridge elements should be allowed to dry before re-installing

Sand Filter

- 1. Have pump running and filter in backwash mode. Suction should come primarily from skimmer, not main drain
- 2. Add 1L bottle of Filter Perfect to skimmer
- 3. Once contents of bottle have entered the filter, turn pump off and put valve in either close or filter position, for a minimum of 6 hours
- 4. Turn pump on with filter set to backwash, run until water flows clear (Do NOT allow pump to run dry)
- 5. Return filter to normal operation